



SAUTER
Facility Touch Client



SAUTER EY-TC505F110
Facility Touch Client software
Commissioning

Manual
D100238860

Contents

1	Preface	5
2	About this manual	7
2.1	Purpose of the manual	7
2.2	Trademarks	7
2.3	Abbreviations	7
2.4	Symbols used in this manual	7
3	Safety information	9
4	Product structure	9
5	Further documentation	9
6	Installation	11
6.1	Requirements of the target system	11
6.2	Preconfiguration of the target system	11
6.2.1	Security	11
6.3	Installation procedure	11
7	Configuration	13
7.1	With CASE Sun and CASE TCM (Touch Configuration Manager)	13
7.1.1	Network configuration	13
7.1.2	CASE Touch Configuration Manager	14
7.1.3	Configuration wizard	15
7.1.4	Blink mode	19
7.2	Configuration on the device	19
7.2.1	Network interface (Configure the network interface)	22
7.2.2	Minimising and closing Facility Touch Client (Minimize/Exit)	22
7.2.3	Other configurations	22
7.2.4	Symbols of possible system messages	22
8	Useful information	25
8.1	Facility Touch Client process list	25

1 Preface

What is Facility Touch Client?

Facility Touch Client (FTC) is a software product for Windows systems that can be used as a web client in the kiosk mode. The software is used to operate moduWeb Vision.

The following functions are covered by this software:

- Presentation of web content without an additional web browser
- Presentation in full screen mode
- Kiosk mode
- Virtual keyboard for different languages
- Optimisation for touch operation (scrolling & drop-down)
- Automatic restart of the web visualisation
- Auto-login with default user
- Centralised commissioning with CASE Sun and Touch Configuration Manager (TCM)

2 About this manual

2.1 Purpose of the manual

This manual is intended for authorised SAUTER employees who commission the Facility Touch Client.

To understand the manual, a certain degree of knowledge of building technology, HVAC installations, control technology and information technology (IT) is required.

It is assumed that the building technology system has been installed and commissioned by SAUTER specialists.

2.2 Trademarks

Windows, Windows 7, WES7 and Windows 8.1 are registered trademarks of Microsoft Corporation.

2.3 Abbreviations

Abbreviation	Term
CASE	Computer-aided SAUTER engineering
FTC	Facility Touch Client
HTTPS	Hypertext transfer protocol secure
IT	Information technology
PC	Personal computer
SIS	Safety Instrumented System
TCM	Touch Configuration Manager
TCP	Transmission Control Protocol
UDP	User Datagram Protocol
USB	Universal Serial Bus

2.4 Symbols used in this manual



This symbol warns of hazards that may arise as a result of incorrect or careless operation of the system.



This symbol refers to additional information that may be helpful for the manual.

3 Safety information

Intended use

Fr. Sauter AG accepts no liability for any damage caused by the improper installation of FTC.

4 Product structure

- EY-TC505F110 Touch Client software for Windows

This software is an accessory of moduWeb Vision.

- EY-WS500F005 moduWeb500 hardware
- EY-WS505F010 moduWeb Vision software for 800 data points, 75 plant schematics, 25 users
- EY-WS505F020 moduWeb Vision software for 2500 data points, 250 plant schematics, 100 users

moduWeb500 will only run after one of the two moduWeb Vision software variants (EY-WS505F010/F020) has been installed and licensed.

Additional options can be released via optional licences:

- EY-WS505F011 upgrade from EY-WS505F010 to 2500 data points, 250 plant schematics, 100 users
- EY-WS506F100 moduWeb Vision Touch option, incl. various resolutions

The installation and licensing of the software is usually carried out by SAUTER or by a SAUTER system partner. Please contact the party responsible for the installation if, when you open FTC, an information page about missing software or a missing license is displayed instead of the start page.

5 Further documentation

Manual for moduWeb Vision Revision D	7010083001 7010083002 7010083003
--------------------------------------	--

6 Installation

6.1 Requirements of the target system

Operating system	Windows 7, WES7, Windows 8.1
Resolution	800 x 600 pixels or more
Processor	1.6 GHz Intel Atom
RAM	512 MB
Hard disk memory	300 MB free memory space
Network	1 x 100 Mbit Ethernet
Authorisation for installing and updating with CASE Sun	Administrator
Authorisation for use	Network Configuration Operator

6.2 Preconfiguration of the target system

Configuration of an user account that has the necessary authorisation and that is logged in automatically when the system is started.

6.2.1 Security

The use of security products such as firewalls and anti-virus software is recommended. The following ports are enabled during the installation of the standard Windows firewall and must also be configured if there is an additional firewall:

Port 443 TCP	HTTPS protocol for the configuration with TCM
Port 5353 UDP	Bonjour service for the device identification with CASE Sun
Port 5626 TCP	Web services for the configuration with CASE Sun



In order to ensure the full functionality of the FTC, the above-mentioned conditions must be fulfilled.

6.3 Installation procedure

PREREQUISITES:

- Login user with administrator rights.
- Installation software is available locally in the target system or via an external memory medium (e.g. USB stick).

PROCEDURE:

1. Start the installation software.
2. Follow the instructions of the installation wizard.
3. Start FTC via the link on the desktop or from the start menu.

Installation



If the Touch PC has more than one network card, one of these network cards must be selected when FTC is started for the first time. This network interface can then be configured via CASE Sun.


7 Configuration

7.1 With CASE Sun and CASE TCM (Touch Configuration Manager)

The touch panels on which FTC is installed and connected with the network are found by CASE Sun and appear in the device list.

7.1.1 Network configuration

The network configuration of FTC is performed in CASE Sun. CASE Sun detects the devices on which FTC is running.




➔ CASE Sun identifies and lists all the devices with FTC.


Configuration

7.1.2 CASE Touch Configuration Manager

1. Click on one of the listed devices with the right mouse button.
 ➔ The following menu opens:



2. Select “CASE Touch Configuration Manager” to proceed.




- ➔ CASE TCM lists the existing Touch Clients and their details.

There are two ways of starting the configuration wizard:

Assigning multiple FTCs to a moduWeb Vision

1. Use the checkboxes to select, from the list, all the FTCs that you want to connect with a moduWeb Vision.
2. Press the button
- ➔ The following selection menu opens:



3. In the selection menu, choose “Commissioning of touch clients”.


Assigning a single FTC to a moduWeb Vision

1. Press the button in the same row.
- ➔ The configuration wizard opens.

7.1.3 Configuration wizard


Carry out the next six steps in the wizard:

1. Select the moduWeb Vision server.




Configuration

2. Login to moduWeb Vision with the administrator password to obtain the project-related user list and profile list.



3. Use Drag&Drop to assign the client profile to the FTC.



4. Assign a user to the auto-login functionality.

Initialize touch client

1 Server link 2 Authentication 3 Client profile 4 Auto login 5 Advanced settings 6 Download

Drag and drop an user account to activate auto login of the touch client to server.

User name	Role	Auto login user	Name	Location	Screen type
specialist	Specialist				
user	User	user	SBA015066		23.58" 1920 x 1200
floor1	User				
floor2	User				
floor3	User				
guest	Guest				

Back Next Cancel

5. Define the administrator password and assign the preferred language setting to the virtual keyboard.

Initialize touch client

1 Server link 2 Authentication 3 Client profile 4 Auto login 5 Advanced settings 6 Download

Choose the settings applied to all selected touch clients.

Set new admin password for all touch clients
Admin password:

Activate virtual keyboard
Select keyboard layout:


Back Next Cancel




With the administrator password the user can view the configurations on the touch panel and close the FTC application.

Configuration

6. Load the configuration.




➔ FTC is loading.



The configuration is applied immediately after the successful completion of loading. The configured content is loaded.

7.1.4 Blink mode


A blink mode is built into the FTC. It identifies the different touch panels in the list. The blink mode is activated or deactivated in CASE Sun.



7.2 Configuration on the device

The login mask appears if you are not logged into a moduWeb Vision or no auto-login is configured.

1. Select the [Settings] button at the bottom of the screen.




Configuration

➔ The following window appears:



2. After the product is displayed, press the [Advanced] button.


➔ The FTC login mask appears:



3. Enter the administrator password.

i This password is defined with CASE Sun and Case TCM (step 5, section 7.1.3 Configuration wizard).

➡ The following dialogue appears with four tabs:



The [Actions] tab provides three options:


- Configure the network interface
- Minimize Facility Touch Client
- Exit Facility Touch Client

Configuration

7.2.1 Network interface (Configure the network interface)

If the Touch PC has **more than one network card**, one of the network cards must be selected.

1. Enter your administrator password using the settings menu.
2. Select the network interface.



i If the Touch PC only has **one network interface**, this is displayed.

7.2.2 Minimising and closing Facility Touch Client (Minimize/Exit)

The two buttons “Minimize Facility Touch Client” and “Exit Facility Touch Client” on the [Actions] tab are used to minimise or close the FTC. This is only possible after entering the administrator password.


7.2.3 Other configurations

No other configurations are performed on FTC. All the configurations are performed with CASE Sun and CASE TCM.


The current configuration is displayed after the administrator password is entered via FTC.

7.2.4 Symbols of possible system messages


The following section explains the symbols of possible system messages:




Error: The connection to the server could not be established.



Locked: When the FTC is locked via TCM, e.g. for maintenance work.



Error: FTC is not configured.



Connection is too slow. If a page loads too slowly (10 seconds or more), three buttons appear below the progress display (grey disc with %): [Back], [Reload] and [Home]. If the page is not loaded, use these buttons.

8 Useful information

8.1 Facility Touch Client process list

If FTC crashes, the following processes are closed automatically and can be restarted:

- java.exe
- Facility Touch Client.exe
- LighTPD.exe
- TcRestServer.exe
- ucfgd.exe
- WebWrapper.exe
- wscserver.exe

The following processes are executed for a limited time during the running time:

- ActionClient.exe
- cmd.exe
- elog.exe
- NetworkHelper.exe
- ucfg.exe

© Fr. Sauter AG
Im Surinam 55
CH-4016 Basel
Tel. +41 61 - 695 55 55
Fax +41 61 - 695 55 10
www.sauter-controls.com
info@sauter-controls.com

Printed in Switzerland