

RCP 40: Damper control unit

How energy efficiency is improved

Enables the implementation of individually optimised controls for maximum efficiency in pneumatic installations.

Areas of application

Activation of a temperature-dependent outside-air/return-air damper in combination with a transducer in ventilation and air-conditioning equipment. Control of the mixed-air temperature with two separate transducers, e.g. in winter operating mode.

Features

- Control of fresh air damper, depending on trapezium diagram for the outdoor temperature
- Housing, rack and front doors made of thermoplastic
- Suitable for wall or panel mounting
- Functional description and commissioning help inserted in front door
- Front panel with adjusters and 3 covered recesses for plug-in pressure gauge (XMP) making commissioning easier
- All settings very easy to make with a coin and % scale
- M4 measuring connections, control action adjustable (delivered with control action B)
- Compressed-air connections Rp 1/8" female thread
- Complies with directive 97/23/EC Art. 3.3 on pressure equipment

Technical description

- Supply pressure 1.3 bar ± 0.1
- Easily accessible adjusters for KP3+5 (schedule start point), XP3+5 (P range)
- Inputs for:
 - control action
- Outputs for:
 - output pressure for damper drive

Туре	Description	Air Capacity I _n /h	Air consumption ¹⁾ I _n /h	Weight kg
RCP 40 F001	trapezium diagram	400	70	0,7
Supply pressure 2) Input pressures	1,3 bar ± 0,1 0,21,0 bar	Permissible amb. temp.		055 °C
Output pressures Shift starting pt. KP ₃ , KP	0,21,0 bar	Connection diagram Dimension drawing		A02692 M297100
P-band X _{P3} , X _{P5} Minimum limiter B	0100% 0100%	Fitting inst	•	MV 3247

Accessories

0297103 000 Additional bag of scales with 8 different scales according to the transducer used. Universal scales for setpoint adjuster X_S; gradation 120, 80/160, 50/100, 30/60 0297133 000

- Without transducer; air consumption for transducer connections 3 and 5 is 33 ln/h more in each case.
- 2) See Section 60 on regulations concerning the quality of supply air, especially at low ambient temperatures.

Operation

The pressure at connections 3 and 5 is fed in each case to an amplifier with variable shift starting point KP (zero point) and variable P-band X_P (amplification). The amplifier at input 3 has control action A; the one at input 5 has control action B. Due to the following minimum selection, the smaller of the two amplifier outputs is always passed on. This forms a trapezoidal characteristic which can be rotated at the KP points (at 0 bar). Both characteristics are limited to a (variable) minimum value by the following


In its main use, a transducer is fed to both inputs, e.g. for the control of a fresh-air damper dependent on outside temperature (trapezium diagram).

The fresh-air damper can also be controlled with dependency on two separate transducers, e.g. damper control dependent on outside temperature in summer, and control of the mixed-air temperature in winter.

A restrictor (Ø 0,2 mm) for supplying the transducer is fitted at connection 3. If a second transducer is connected to connection 5, then a separate restrictor (Ø 0,2 mm) is needed. The signals from the transducer (connections 3 and 5) and the output pressure can be checked via the M4 measuring connection or indicated via the manometer.







Fresh-air damper

B03259

Additional details

Front plate with adjusters for P-bands (X_{P3}, X_{P5}), shift starting point (KP3, KP5) and limitation (B).

Additional information on accessories

0297103 000 Additional bag of eight alternative scales


5...35 °C 20...90 %rh –20...40 °C 0...5 mbar 0...120 °C 5...10 mbar 80...200 °C 10...15 mbar

Technical information


Technical manual: centair system 304991 003

Connection diagrams

Damper control for summer and winter



Open-loop control in summer, closed-loop control in winter



- Supply pressure 1
- 2 Output pressure
- 3 Input for control action A (winter) 5
 - Input for control action B (summer)
- KP3 Shift starting point, summer
- KP5 Shift starting point, winter
- XP_3 P-band, summer XP₅ P-band, winter
- В Minimum limiter

У

- Mixed-air temperature
- x_{i3} Outside temperature X_{i5}
 - Output pressure

Dimension drawing

